



---

## AXLE OPERATING MANUAL

2525 Cabot Dr., Suite 310, Lisle, IL 60532  
312.312.7767 | [service@terranaxle.com](mailto:service@terranaxle.com) | [www.terranaxle.com](http://www.terranaxle.com)



---

## Table of Contents

1.	INTRODUCTION .....	3
2.	SAFETY INFORMATION.....	3
3.	RECOMMENDED NEW AXLE SETTINGS AND ADJUSTMENTS .....	4
4.	HUBS, DRUMS AND BEARINGS .....	4
4.1	Drum Removal and Bearing Lubrication .....	5
4.2	Brake Drum Check.....	6
4.3	Seal Check and Replacement .....	6
4.4	Idler Hub Removal and Inspection Procedure.....	6
4.5	Spindle Nut Torquing Procedure.....	7
4.6	EZ Lubrication .....	7
5.	AXLE & SUSPENSION SYSTEM.....	7
5.1	Installation of Axle with Double Eye Leaf Springs.....	9
5.2	Installation of Axle with Slipper Leaf Springs .....	11
5.3	Torsion Suspension System.....	12
5.4	Bushing Replacement Procedure.....	14
5.5	Installation of AP Kit .....	15
5.5.1	Suspension Fastener Torque Values.....	17
6.	BRAKING SYSTEMS - ELECTRIC .....	17
6.1	General Maintenance – Electric Brakes .....	19
6.2	Brake Cleaning and Examination.....	20
6.2.1	Electromagnet .....	20
6.2.2	Brake Lubrication.....	21
6.2.3	Voltage Measurements .....	21
6.2.4	Troubleshooting Electric Brakes .....	23
6.3	Hydraulic Brakes.....	24
6.3.1	Lubrication .....	24
7.	WHEELS & TIRES .....	25
7.1	Wheels Selection .....	25
7.2	Wheel Installation .....	25
7.2.1	Torque Requirements .....	25
7.3	Tire Selection .....	26



---

7.4	Tire Installation and Maintenance .....	27
8.	POST-AXLE INSTALLATION CHECKLIST .....	28
9.	RECOMMENDED MAINTENANCE PROCEDURES & SAFETY CHECKS .....	29
10.	LIMITED WARRANTY .....	30
11.	AXLE SPECIFICATIONS .....	30



---

# OPERATING MANUAL FOR TERRAN INDUSTRIES

## 1. INTRODUCTION

This operating manual provides important information for the service and maintenance of axles and component parts manufactured by Terran Industries (“Terran”). This operating manual is not comprehensive but addresses the most common axle service and maintenance procedures.

**Safety is our top priority.** This operating manual furnishes important information for safe and proper servicing and maintenance. Given the wide range of procedures for axle service and maintenance, this operating manual is only able to address a limited number of procedures. In the event an owner or qualified technician deviates from these procedures, it is important to consider (i) safety in performing the service or maintenance, (ii) the impact of the procedure on safe and efficient axle functioning and (iii) that failure to comply with these procedures renders the Terran warranties null and void. **Before road operation, it is important to confirm that the axle and component parts are operating properly.**

Be sure to review the operating manuals for your tow vehicle, trailer and key component parts before initiating service or maintenance. For your safety, please review this manual closely and if you have any questions, please contact your trailer manufacturer or visit our website at [www.terranaxle.com](http://www.terranaxle.com).

From our experience in the trailer axle industry, we designed our axles and component parts to meet our customers’ needs. Terran bearings, spindles, brakes, drums, hubs, beams and other component parts reflect our commitment to deliver dependable and durable axles.

## 2. SAFETY INFORMATION

It is critically important that service and maintenance be performed in accordance with tow vehicle, trailer and component parts’ operating manuals. Failure to follow prescribed procedures may result in serious injury or death to the persons performing the service or maintenance as well as to vehicle occupants and others from road operation. Given the numerous variations in service and maintenance procedures across the spectrum of tow vehicles and trailers, this manual does not provide comprehensive instructions for performance of service and maintenance under all conditions. If any procedures are either not fully understandable, do not address your specific question, or you lack the necessary equipment for the safe completion of the procedure, contact a qualified technician to advise on or to perform the procedure before returning the trailer to operation. If a procedure is not performed in accordance with the applicable tow vehicle, trailer or other operating manuals, the Terran warranty is null and void.

### CAUTION

**FOLLOW ALL SAFETY PRECAUTIONS SET FORTH IN THIS MANUAL AND ALL MANUALS FOR YOUR TRAILER, TOW VEHICLE AND COMPONENT PARTS.**

Please pay close attention to the caution alerts (under heading “**CAUTION**”) and the specific instructions for safety measures and certain risks involved in each procedure. Importantly, this operating manual is instructive but not comprehensive and all risks from each service and maintenance procedure cannot be fully addressed. Failure to follow these procedures (and other safety protocols not addressed in this operating manual) could result in injury and death, lead to axle and trailer malfunction and result in dangerous road operation.



### CAUTION

ALWAYS USE EYE PROTECTION (SAFETY GLASSES) WHEN UNDERTAKING ANY SERVICE, MAINTENANCE OR OTHER PROCEDURE IN THIS MANUAL. FAILURE TO DO SO MAY RESULT IN SERIOUS PHYSICAL INJURY AND PERMANENT PHYSICAL DAMAGE.


### 3. RECOMMENDED NEW AXLE SETTINGS AND ADJUSTMENTS

<b>Wheels</b>	Wheel Nut Torque Check*	At 50, 1000, 2000 and every 3000 miles thereafter
<b>Tires</b>	Tire Pressure	Manufacturer recommendations
<b>Brakes</b>	Adjustment	At 250 miles and every 3000 miles thereafter
<b>Bearings</b>	Inspection / Lubrication	After initial 3000 miles, then annually or every 36,000 miles

\*See torque values for wheels under section entitled “Wheels & Tires.”

### 4. HUBS, DRUMS AND BEARINGS

Terran hub, drum and axle component part configuration follows industry standards. Each axle is assembled and inspected according to factory specifications; before use, it is good practice to check for proper rotation of the brake drum assemblies to ensure bearings are seated and pre-loaded. Each brake drum should rotate freely with very slight drag. There should be no excessive drag, play, looseness or wobbling of the drum to spindle connection.



1	Brake Drum
2	Grease Seal, Double Lip
3	Race
4	Bearing
5	Dust Cap
6	Wheel Nuts
7	EZ Lube Spindle
8	Spindle Nut
9	Cotter Pin
10	Spindle Washer, Flat Round
11	Grease fitting




## CAUTION

**RAISE TRAILER ONLY WITH A SUITABLE FLOOR JACK AND JACK STANDS WHICH ARE APPROVED FOR THE LOAD. ATTACH JACK STANDS TO FRAME AND NEVER ATTACH JACK STANDS TO THE AXLE OR SUSPENSION. NEVER GO UNDER THE TRAILER UNLESS TRAILER IS SECURELY SUPPORTED BY JACK STANDS APPROVED FOR THE LOAD. FAILURE TO SECURELY SUPPORT THE TRAILER MAY CAUSE SERIOUS INJURY OR DEATH.**

### 4.1 Drum Removal and Bearing Lubrication

The drum will be removed for a number of procedures in this operating manual, including bearing lubrication. The recommended procedure to remove and repack bearings follows (with reference to the corresponding photo):


1. Ensure your trailer is on a level surface and follow the manufacturer's instructions for wheel removal, including safely jacking up the trailer on jack stands designed to support your trailer type, size, and weight.
2. Loosen and remove lug nuts and wheel.
3. Once the wheel is off, using a rubber mallet, gently tap the perimeter of the dust cap until it releases. [photo #1].
4. Remove cotter pin by straightening the ends with pliers and prying the cotter pin from the spindle.
5. Remove the spindle nut using a wrench with a 38mm socket (2K-7K axles) [photo #2].
6. Remove the spindle washer.
7. Remove the brake drum from the spindle (should retain the outer bearing assembly) [photo #3].
8. Remove the outer bearing [photo #4]. Place it in a safe place, preventing dust or debris from entering that could contaminate the grease in the bearing.
9. Remove the grease seal and inner bearing. With either a seal puller tool or a screwdriver, carefully pry out the seal without causing damage. Examine the grease seal for wear and damage. If worn or damaged, replace it to ensure a proper seal. If necessary, try to use the inside diameter of the seal and the hub face as leverage points and gently pry up around the perimeter seal circumference [photo #5]. Note: The seal cannot be use after being removed with a screwdriver.



10. Clean and remove all grease from the bearings and examine for damage or wear. Be sure to inspect the bearing race and spindle surface for wear or other damage.
11. If you do not have a bearing grease packer tool, wearing gloves put grease onto your hand and place the bearing into the grease, moving the bearing until each roller and all gaps are fully packed with grease. Repeat for each bearing [photo #6].
12. Insert the cleaned and repacked inner bearing into the hub (on the back side) [photo #7].
13. Insert the grease seal into the hub with the rubber side facing in. If you do not have a bearing/race removal tool, carefully tap the seal with a block of wood until the seal is flat against the hub surface. Grease the seal lip.
14. Return the brake drum to the spindle and replace parts in the same order in which the parts were removed (repacked outer bearing, washer and spindle nut). Tighten the spindle nut following 4.5 Spindle Nut Torquing Procedure steps 4-9.
15. While slowly rotating the idler hub, pump grease slowly into the fitting and when new grease is seen protruding from the front of the spindle, remove the grease gun and clean excess grease [photo #8 4.1 Drum removal and bearing lubrication section]. Use Mobil XHP 222 grease for better performance.



16. Reinstall the dust cap with rubber mallet.
17. Give the hub/drum a final spin to ensure smooth rotation.



#### 4.2 Brake Drum Check

To check the condition of brake parts, follow the above drum removal procedure to closely examine (i) the drum surface where the brake shoes make contact to examine the level of wear and (ii) for electric brakes, the armature surface where it makes contact with the electromagnet. For the drum surface, check for scoring and wear. Follow a qualified technician's recommendations on whether a drum surface should be resurfaced or replaced. **Terran does not advise on whether or not the drum surface should be resurfaced or replaced.**

The area of a drum that makes contact with the electromagnet is the armature surface. If the armature surface shows wear, consult with a qualified technician to assess refinishing. Electromagnets should be replaced when the armature surface is refinished; conversely, when electromagnets are replaced, a qualified technician should determine whether to refinish the armature surface to maintain the proper contact with the electromagnet. Instead of refinishing the armature surface, oftentimes replacement is advised by a qualified technician.

#### 4.3 Seal Check and Replacement

With either a seal puller tool or a screwdriver, follow the above drum removal procedure to carefully pry out the seal without causing damage. If necessary, use the inside diameter of the seal and the hub face as leverage points for the screwdriver to gently pry up around the perimeter seal circumference. Examine the grease seal for wear and damage whenever the hub is removed. If worn or damaged, replace to ensure a proper seal.

#### CAUTION

**RAISE TRAILER ONLY WITH A SUITABLE FLOOR JACK AND JACK STANDS WHICH ARE APPROVED FOR THE LOAD. ATTACH JACK STANDS TO FRAME AND NEVER ATTACH JACK STANDS TO THE AXLE OR SUSPENSION. NEVER GO UNDER THE TRAILER UNLESS TRAILER IS SECURELY SUPPORTED BY JACK STANDS APPROVED FOR THE LOAD. FAILURE TO SECURELY SUPPORT THE TRAILER MAY CAUSE SERIOUS INJURY OR DEATH.**

#### 4.4 Idler Hub Removal and Inspection Procedure

1. Ensure your trailer is on a level surface and follow the manufacturer's instructions for wheel removal, including safely jacking up the trailer on jack stands designed to support your trailer type, size and weight.
2. Loosen and remove lug nuts and wheel.
3. Once the wheel is off, using a rubber mallet, gently tap the perimeter of the dust cap until it releases. Remove cotter pin by straightening the ends with pliers and prying the cotter pin from the spindle.
4. Remove the spindle nut using a wrench with a 38mm socket (2K-7K axles)
5. Remove the spindle washer.
6. Remove the idler hub from the spindle (should retain the outer bearing assembly).
7. Remove the outer bearing. Place it in a safe place, preventing dust or debris from entering that could contaminate the grease in the bearing.
8. Inspect the idler hub surface for wear and any damage. If the idler hub surface is worn or scored, consult with a qualified technician for idler hub repair or replacement.



9. Return the idler hub to the spindle and replace parts in the same order in which the parts were removed (repacked outer bearing, washer and castle spindle nut). Tighten the spindle nut following steps 4.5 Spindle Nut Torquing Procedure steps 4 to 9.
10. While slowly rotating the idler hub, pump grease slowly into the fitting and when new grease is seen protruding from the front of the spindle, remove the grease gun and clean excess grease [photo #8 4.1 Drum removal and bearing lubrication section]. Use Mobil XHP 222 grease for better performance.
11. Reinstall the dust cap with rubber mallet.
12. Give the hub/drum a final spin to ensure smooth rotation.

#### 4.5 Spindle Nut Torquing Procedure

1. Remove the dust cap using rubber mallet.
2. Carefully remove the cotter pin with pliers without causing damage.
3. Loosen the spindle nut with torque wrench using a size 38mm socket.
4. Tighten the spindle nut with torque wrench set at 61.5 FT/LB for 3500 lb. to 4400 lb. axle capacity, or 88.5 FT/LB for 6000-7000 lb. axle capacity axle, until you hear two clicks.  
*Note: The higher torque removes any tension and overload on the bearing/cup/cone.*
5. Rotate the hub/drum 90°.  
*Note: This applies even force inside the bearing.*
6. Loosen the spindle nut approximately 90-120°.
7. Tighten the spindle nut with torque wrench set at 43.4 FT/LB for 3500 lb. to 4400 lb. axle capacity axle, or 73.76 FT/LB for 6000-7000 lb. axle capacity, until you hear two clicks.  
*Note: This is the normal torque for bearing load which leaves no space between the cup and cone.*
8. Reverse the spindle nut 90°, not exceeding 100°, to align the cotter pin hole.  
*Note: This range leaves proper space between the cup and cone for grease.*
9. Insert the cotter pin with pliers. (Use a new cotter pin if needed)
10. Apply more grease if needed, using Mobil XHP 222.
11. Install the dust cap with rubber mallet.
12. Give the hub/drum a final spin to ensure smooth rotation.

#### 4.6 EZ Lubrication

##### CAUTION

**DUE TO POSSIBLE DANGEROUS CHEMICAL REACTIONS, DO NOT MIX GREASES, ESPECIALLY THOSE CONTAINING LITHIUM, CALCIUM, SODIUM OR BARIUM. WHEN USING NEW GREASE, COMPLETELY REMOVE ALL EXISTING GREASE PRIOR TO APPLYING NEW GREASE. FAILURE TO REMOVE OLD GREASE BEFORE APPLYING NEW GREASE COULD RESULT IN COMPONENT FAILURE AND DAMAGE RESULTING IN MECHANICAL INOPERABILITY OR FAILURE.**

The following procedure is recommended for utilizing the E-Z lubrication feature:

\*Use Mobil XHP 222 for better performance.

1. Ensure your trailer is on a level surface and follow the manufacturer's instructions for wheel removal, including safely jacking up the trailer on jack stands designed to support your trailer type, size, and weight.
2. Remove the rubber plug from the end of the grease cap.
3. Insert a grease gun nozzle onto the grease fitting at the end of the spindle.
4. While slowly rotating the idler hub or drum, pump grease slowly into the fitting and when new grease is seen protruding from the front of the spindle, remove the grease gun and clean excess grease.
5. Return the rubber plug to the end of the grease cap.

## 5. AXLE & SUSPENSION SYSTEM

Axle suspensions are designed to absorb shock from the road, maintain trailer balance while in motion, improve ride evenness and alleviate wear on and damage to your trailer frame, wheels, and tires.






**Alignment.** Ensure proper alignment by checking axle alignment on both sides. The axle must be parallel to the drive axle of the tow vehicle. To measure alignment, use a tape measure or other device from the center of the front king pin pivot mount to the center line of each axle end. There should be no more than 1/16" difference between each side measurement. If this measurement exceeds this 1/16" then other underlying issues are present with your frame or mounting points. These issues need to be addressed and repaired before proceeding.

**Inspection.** Inspect all axle components at least every 5,000 miles for signs of wear, elongation of bolt holes and loosening of fasteners. Any replaced fasteners should be torqued pursuant to the specifications in the torque value chart below.

**Configuration of Axle Components.**



1	Integrated Flange Spindle	11	Inner Bearing, Race
2	Brake Flange	12	Brake Drum
3	Spring Seat	13	Outer Bearing, Cup
4	U-Bolt	14	Outer Bearing, Race
5	Tie Plate	15	Spindle Washer, Flat Round
6	Nut Flange	16	Spindle Nut
7	Leaf Spring, Double-Eye	17	Cotter Pin
8	Brake Assembly	18	Dust Cap
9	Grease Seal, Double Lip	18A	Rubber Plug for Dust Cap Hole
10	Inner Bearing, Cone	19	Wheel Nut


**Axle Examination Prior to Installation.** Proper axle installation and alignment is the responsibility of the axle installer. Prior to installation, inspect your trailer frame and mounting components for durability and soundness. Never attempt to mount your new axle assembly to broken, cracking or rusted mounting points. This could result in mounting point failures during installation and on the road lead to potential injury or death. Repair or replace all damaged or aging mounting components prior to installation. Use new and appropriately-sized mounting fasteners. Rusted and



fatigued bolts and nuts lose strength after repeated usage from wear and tear. Also, closely examine the condition of any existing nylon bushings on equalizers and leaf spring ends.

### 5.1 Installation of Axle with Double Eye Leaf Springs

**Double Eye Leaf Springs.** Double eye leaf springs have a bolt hole at the end of each spring. Each leaf curls at the end and attaches to the suspension bolts at each end of the spring. Double eye leaf spring suspensions are comprised of the following component parts: Hangers, leaf springs, shackle link assemblies, shackle links, bushings, suspension bolts, U-Bolts, U-bolt plates and spring seats. Equalizers and matching mounting brackets may also be used for tandem axle installations.



5A Link assemblies come with shackle bolts installed.

5B Shackle links are loose parts that attach to the other side of the shackle link assemblies.

1	Front Hanger	7	Lock Nuts
2	Rear Hanger	8	Leaf Spring
3	Center Hanger	9	Spring Seat
4	Equalizer	10	U-Bolt
5A	Shackle Link Assemblies	11	U -Bolt Plate
5B	Shackle Links	12	U-Bolt Nut Flange
6	Shackle Bolt		



---

## CAUTION

**RAISE TRAILER ONLY WITH A SUITABLE FLOOR JACK AND JACK STANDS WHICH ARE APPROVED FOR THE LOAD. ATTACH JACK STANDS TO FRAME AND NEVER ATTACH JACK STANDS TO THE AXLE OR SUSPENSION. NEVER GO UNDER THE TRAILER UNLESS TRAILER IS SECURELY SUPPORTED BY JACK STANDS APPROVED FOR THE LOAD. FAILURE TO SECURELY SUPPORT THE TRAILER MAY CAUSE SERIOUS INJURY OR DEATH.**


The following procedure details the installation of the axle with double eye leaf springs:

1. Ensure your trailer is on a level surface and follow the manufacturer's instructions for safely raising the trailer on jack stands designed to support your trailer type, size and weight.
2. If replacing existing axles, remove the prior axle assembly using best practices and appropriate safety measures.
3. Thoroughly inspect the new axle and components and carefully position your axle under the frame.
4. Position the axle assembly with the manufacturer label facing the rear of the frame. This will orientate the mounted brakes to the correct rotational position.
5. **FRONT CHASSIS SPRING INSTALLATION.** Insert the leaf springs into the front chassis hanger, align the spring eyes to the hanger holes and install the shackle bolts from the outside of the frame, loosely install the lock nuts on the inside of the hangers. Follow steps 9 to 11 for final installation.
6. **REAR CHASSIS SPRING INSTALLATION. For Single Axle.** Insert the Shackle Link Assemblies from the outside of the chassis into the other leaf spring eyes and the rear chassis hangers, install the shackle link into the shackle link assemblies, loosely install the lock nuts on the inside. Follow steps 9 to 11 for final installation.
7. **REAR CHASSIS SPRING INSTALLATION. For Tandem Axles.** Align the axle equalizer into the center chassis hanger hole and install the shackle bolt from the outside of the chassis, loosely install the lock nuts on the inside. Insert the shackle link assembly into the front axle leaf spring eye and into the equalizer hole, install the shackle links into the shackle links assemblies and loosely install the lock nuts on the inside.  
Once front axle springs are installed, insert the other shackle link assemblies from the outside into the rear axle spring eyes, then insert them into the equalizer eye, loosely install the lock nuts on the inside of the hangers. Insert the shackle link assemblies from the outside into the other side of the springs, then insert the other side of the shackle links assemblies into the rear chassis hanger hole, loosely install the lock nuts on the inside of the hangers. Follow steps 9 to 11 for final installation.
8. **REAR CHASSIS SPRING INSTALLATION. For Triple Axles.** Align the front axle equalizer into the second chassis hanger holes and install the shackle bolt from the outside of the chassis, loosely install the lock nuts on the inside.  
**First Axle.** Insert the shackle link assembly into the front axle leaf spring eye and into the equalizer hole, install the shackle links into the shackle links assemblies and loosely install the lock nuts on the inside.  
**Second Axle.** Insert and align the center axle spring eye into the triple axle equalizer, install the shackle bolt from the outside, loosely install the lock nuts on the inside of the hangers. Insert the shackle link assembly into the center axle leaf spring eye and into the rear equalizer hole, install the shackle links into the shackle links assemblies and loosely install the lock nuts on the inside.  
Align the rear axle equalizer into the third chassis hanger hole and install the shackle bolt from the outside of the chassis, loosely install the lock nuts on the inside.  
Insert the other shackle link assemblies from the outside into the center axle spring eyes, then insert them into the second equalizer eye, loosely install the lock nuts on the inside of the hangers.  
**Third Axle.** Once middle axle springs are installed, insert the other shackle link assemblies from the outside into the rear axle spring eyes, then insert them into the second equalizer eye, loosely installing the lock nuts on the inside of the hangers. Insert the shackle link assemblies from the outside into the other side of the rear axle springs, then insert the other side of the shackle links assemblies into the rear chassis hanger hole, loosely install the lock nuts on the inside of the hangers. Follow steps 9 to 11 for final installation.
9. Using a 3-pound hammer strike the head side of the mounting bolt until it is fully flush with the hanger face. This is required as the mounting bolt has splines around the head shank diameter to seat the mounting bolt securely into the bracket. Tighten the mounting bolt using a wrench to hold the head and an impact tool/wrench with the proper socket. Fully tighten the mounting nuts using the impact tool/wrench and proper fitting socket. Continue to tighten until seeing 2-3 threads out. Repeat this procedure for the rear leaf spring and the other side of the axle.
10. Ensure that other ancillary frame pivot mounts are properly secured.
11. Connect either hydraulic brake lines for hydraulic brakes or electrical brake wires for electric brakes.
12. Test the brakes.



## 5.2 Installation of Axle with Slipper Leaf Springs

**Slipper Leaf Springs.** Slipper leaf springs have a bolt hole on one end and the other slipper end slides into the appropriate hanger or equalizer attached to the trailer frame. Slipper leaf springs suspensions are comprised of the following primary component parts: hangers, leaf springs, bushings, suspension bolts, U-Bolts, U-bolt plates and spring seats. Equalizers and matching mounting brackets may also be used for tandem axle applications.



1	Front Hanger	9	Castle Nut
2	Center Hanger	10	Hex Lock Nut
3	Rear Hanger	11	Cotter Pin
4	Equalizer	12	Leaf Spring
5	Shackle Bolt	13	Spring Seat
6	Equalizer Bolt	14	U-Bolt
7	Spring Keeper Bolt	15	U-Bolt Plate
8	Hex Lock Nut*	16	U-Bolt Nuts Flange



---

## CAUTION

**RAISE TRAILER ONLY WITH A SUITABLE FLOOR JACK AND JACK STANDS WHICH ARE APPROVED FOR THE LOAD. ATTACH JACK STANDS TO FRAME AND NEVER ATTACH JACK STANDS TO THE AXLE OR SUSPENSION. NEVER GO UNDER THE TRAILER UNLESS TRAILER IS SECURELY SUPPORTED BY JACK STANDS APPROVED FOR THE LOAD. FAILURE TO SECURELY SUPPORT THE TRAILER MAY CAUSE SERIOUS INJURY OR DEATH.**

The following procedure is recommended for the installation of an axle with slipper leaf springs:

1. Ensure your trailer is on a level surface and follow the manufacturer's instructions for safely raising the trailer on jack stands designed to support your trailer type, size and weight.
2. If replacing existing axles, remove the prior axle assembly in accordance with best practices and appropriate safety measures.
3. Thoroughly inspect the new axle and components and carefully position your axle under the frame.
4. Position the axle assembly with the manufacturer label facing the rear of the frame. This will orientate the mounted brakes to the correct rotational position.
5. Align the slipper side of the leaf spring and insert into the hanger or equalizer, as applicable.
6. Align the spring eye end of the leaf spring to the other hanger or equalizer, as applicable.
7. Insert the bolt from the outside of the frame and insert the bolt through the bracket and leaf spring eye end. Install the nut on the inside of the bracket. Using a 3-pound hammer strike the head side of the mounting bolt until it is fully flush with the hanger face. This is required as the mounting bolt has splines around the head shank diameter to seat the mounting bolt securely into the bracket. Fully tighten the mounting nuts using the impact tool/wrench and proper fitting socket. Continue to tighten until seeing 2-3 threads out. Repeat this procedure for the other side of the axle.
8. Ensure that other ancillary frame pivot mounts are properly secured.
9. Connect either hydraulic brake lines for hydraulic brakes or electrical brake wires for electric brakes.
10. Test the brakes.


### 5.3 Torsion Suspension System

The Terran Torsion Suspension System ("Torsion Axle") is a torsion arm suspension structure completely contained within the axle tube. It attaches directly to the trailer frame using brackets which are a critical part of the Torsion Axle assembly.

The Torsion Axle design has a steel torsion bar surrounded by four (4) natural rubber cords within the main structure of the axle beam. In operation, suspension is provided through the mechanics of this Torsion Axle design.




## Torsion Suspension System



As depicted above, the axle spindle is attached to a torsion arm which is fastened to a rubber-encased torsion bar. In operation, as load is applied, the torsion bar rotates causing a rolling and generating compressive resistance in the rubber cords within the axle beam. This action is designed to offer the same suspension function as conventional spring axles with certain distinguishing features, including independent suspension. As with all best practices for safety and optimal function, periodic inspection is always recommended. At minimum, Torsion Axles should be inspected in accordance with the inspection procedures for suspension system components as set forth in this manual.

### CAUTION

**DO NOT WELD ON THE TORSION BEAM, TORSION ARM OR TORSION BAR. IT HAS RUBBER CORDS INSIDE AND THE HEAT GENERATED BY WELDING COULD DAMAGE THE CORDS.**



Bolt Size	Axle Weight Capacity	Torque Range
9/16	3500 lb	90-100 FT/LB
5/8	6000 lb to 10000 lb	120-130 FT/LB

#### 5.4 Bushing Replacement Procedure

#### CAUTION

**RAISE TRAILER ONLY WITH A SUITABLE FLOOR JACK AND JACK STANDS WHICH ARE APPROVED FOR THE LOAD. ATTACH JACK STANDS TO FRAME AND NEVER ATTACH JACK STANDS TO THE AXLE OR SUSPENSION. NEVER GO UNDER THE TRAILER UNLESSTRAILER IS SECURELY SUPPORTED BY JACK STANDS APPROVED FOR THE LOAD. FAILURE TO SECURELY SUPPORT THE TRAILER MAY CAUSE SERIOUS INJURY OR DEATH.**

**Bushing Replacement.** Our axles utilize nylon bushings for spring eye axle ends and equalizer pivots. The frequency of bushing replacement depends upon on your mileage and type of usage. This procedure applies to spring eye axle ends and equalizer bushing replacement.

1. Ensure your trailer is on a level surface and follow the manufacturer's instructions for wheel removal, including safely jacking up the trailer on jack stands designed to support your trailer type, size and weight.
2. Loosen and remove lug nuts and wheel.
3. Loosen nut on spring through bolt. Do not remove.
4. Place a secondary jack under the axle U-bolt spring plate. Slowly raise the axle enough to relieve spring pressure on the mounting hanger/shackle straps/equalizer.
5. Tap out the mounting bolt by striking the lock nut to dislodge the serrated bolt head from its mounting.
6. Remove mounting bolt and nut. The spring should now be free from the mounting point.
7. Remove spring eye bushing. In most cases the bushing will simply fall out. If not, then use an appropriately sized socket to tap the bushing out.
8. Inspect the inside diameter of the spring eye and clean and remove any debris or dirt.
9. Install new bushing into the spring eye. If necessary, tap the bushing in using a ~~wood block~~ rubber mallet or the appropriate shackle mounting bolt to seat the bushing into the spring eye.



10. Reinstall the spring to its original mounting position to the mounting hanger/shackle ~~straps~~ assemblies and shackle links/equalizer.
11. Note: **For Lock Nuts with 3 Teeth Only:** Install new shackle link assemblies, new shackle bolts from the outside of the frame and new lock nut from the inside of the frame. **For Nylon Lock Nut Only:** Inspect shackle assemblies bolts, shackle bolts and Nylon lock nut for any fatigue or rust. Replace it with new if required.
12. Using a 3-pound hammer strike the head side of the mounting bolt until it is fully flush with the hanger face. This is required as the mounting bolt has splines around the head shank diameter to seat the mounting bolt securely into the hanger. Fully tighten the mounting nuts using the impact tool/wrench and proper fitting socket. Continue to tighten until seeing 2-3 threads out.
13. Ensure that other ancillary frame pivot mounts are properly secured.
14. Remove axle jack, reinstall wheel, tighten lug nuts to specified torque values and carefully lower trailer.

### 5.5 Installation of AP Kit

#### CAUTION

**RAISE TRAILER ONLY USING JACK STANDS ATTACHED TO FRAME AND APPROVED FOR THE LOAD. NEVER ATTACH JACK STANDS TO THE AXLE OR SUSPENSION. NEVER GO UNDER THE TRAILER UNLESS THE TRAILER IS SECURELY SUPPORTED BY JACK STANDS APPROVED FOR THE LOAD. FAILURE TO SECURELY SUPPORT THE TRAILER CAN CAUSE SERIOUS INJURY OR DEATH.**


The following procedure details the installation of a single axle with double eye leaf springs:

1. Ensure your trailer is on a level surface and follow the manufacturer's instructions for safely raising the trailer on jack stands designed to support your trailer type, size and weight.
2. If replacing existing axles, remove the prior axle assembly in accordance with best practices and appropriate safety measures.
3. Thoroughly inspect the axle components and carefully position your axle under the frame.
4. Position the axle assembly with the manufacturer label facing the rear of the frame. This will orientate the mounted brakes in the correct rotational position.
5. Insert the required number of shackle bolts into the shackle straps. Make sure the head side of the bolts is fully flush with the shackle assembly surface.
6. Align spring eyes to the front hanger. Insert the bolt from the outside of the frame then insert the bolt through the bracket and leaf spring eye end. Loosely install the lock nut on the inside of the hanger.
7. Align other spring eye to rear hanger. Insert the shackle bolt from the outside of the frame then insert the shackle bolt through the bracket and leaf spring eye end. Place the shackle assembly to the other end of the shackle bolt. Loosely install the lock nut on the inside of the assembly.
8. Using a 3lb mallet, strike the head side of the shackle bolt inserted into the front hanger until it is fully flush with the hanger face. This is required as the shackle bolt has splines around the head shank diameter to seat the shackle bolt securely into the hanger. Fully tighten the mounting nuts using the impact tool/wrench and proper fitting socket. Continue to tighten until seeing 2-3 threads out. Repeat this procedure for the other side of the axle.
9. Connect either hydraulic brake lines for hydraulic brakes or electrical brake wires for electric brakes.
10. Test the brakes.





## Double Eye Spring for Single Axle



### CAUTION

**RAISE TRAILER ONLY USING JACK STANDS ATTACHED TO FRAME AND APPROVED FOR THE LOAD. NEVER ATTACH JACK STANDS TO THE AXLE OR SUSPENSION. NEVER GO UNDER THE TRAILER UNLESS THE TRAILER IS SECURELY SUPPORTED BY JACK STANDS APPROVED FOR THE LOAD. FAILURE TO SECURELY SUPPORT THE TRAILER CAN CAUSE SERIOUS INJURY OR DEATH.**


The following procedure details the installation of the double axles with double eye leaf springs:

1. Ensure your trailer is on a level surface and follow the manufacturer's instructions for safely raising the trailer on jack stands designed to support your trailer type, size and weight.
2. If replacing existing axles, remove the prior axle assembly in accordance with best practices and appropriate safety measures.
3. Thoroughly inspect the axle components and carefully position your axle under the frame.
4. Position the axle assembly with the manufacturer label facing the rear of the frame. This will orientate the mounted brakes in the correct rotational position.
5. Insert the required number of shackle bolts to the shackle straps. Make sure the head side of the bolts is fully flush with the shackle strap surface.
6. Align spring eyes to the front hanger. Insert the bolt from the inside of the frame and insert the bolt through the bracket and leaf spring eye end. Loosely install the lock nut on the outside of the bracket.
7. Align the equalizer to middle hanger; insert the shackle bolt through the hanger and the center hole of the equalizer. Loosely install the lock nut on the outside of the hanger.
8. Insert the shackle bolt into the other spring eye of the front axle and the equalizer. Place the shackle assembly to the other end of the shackle bolt. Loosely install the lock nut on the outside of the shackle link.
9. Align the spring eye of the rear axle to the rear hanger. Insert the shackle bolt from the outside of the frame and insert the bolt through the hanger and leaf spring eye end. Loosely install the lock nut on the inside of the hanger.
10. Insert the shackle bolt into the equalizer and the other spring eye of the rear axle. Place the shackle assembly to the other end of the shackle bolt. Loosely install the lock nut on the outside of the shackle link.



11. Using a 3lb mallet, strike the head side of the shackle bolt inserted into the front, middle and rear hangers until they are fully flush with the bracket face. This is required as the shackle bolt have splines around the head shank diameter to seat the shackle bolt securely into the brackets. Tighten the shackle bolt using a wrench to hold the head and an impact tool/wrench and proper fitting socket. Continue to tighten until seeing 2-3 threads out. Repeat this procedure for the other side of the axle.
12. Connect either hydraulic brake lines for hydraulic brakes or electrical brake wires for electric brakes.
13. Test the brakes.

### Double Eye Springs for Double Axle




#### 5.5.1 Suspension Fastener Torque Values

Bolt Type & Size	Axle Weight Capacity	Torque
3/8" U-Bolt Nuts	2000 lb	40±3 ft per lb
1/2" U-Bolt Nuts	3500 lb	55±3 ft per lb
9/16" U-Bolt Nuts	3500 lb	73±3 ft per lb
9/16" U-Bolt Nuts	5000 lb to 6000 lb	81±3 ft per lb
9/16" U-Bolt Nuts	7000 lb to 8000lb	88±3 ft per lb
Shackle & Equalizer Nuts <i>* lock nuts only w/ 3 teeth</i>	Double Eye & Slipper Style	Snug Nut Only, 2-3 Threads Out
Shackle & Equalizer Nuts Nylon Lock Nuts	Double Eye & Slipper Style	65±3 ft per lb

## 6. BRAKING SYSTEMS - ELECTRIC

Electric brakes are powered by electrical current that activates an electromagnet in each brake. When activated by the driver pressing the brake pedal, the brake controller sends an electrical current to the electromagnets in the trailer brakes causing the actuating levers to move the brakes shoes against the rotating brake drums, thereby slowing wheel rotation. Increasing electrical current to the electromagnets (from more force on the brake pedal) will elevate the force of the brake shoes on the rotating brake drums and result in greater deceleration. For more information on the brake controller and brake operation, please refer to information provided by your trailer, tow vehicle and controller manufacturers.



### Features of Electronically Actuated Brakes

Electrically actuated brakes have certain advantages over other brake actuation systems:

1. able to be manually adjusted at the controller to provide the correct braking capability for varying road and load conditions;
2. able to be modulated to provide more or less braking force thus easing the brake load on the towing vehicle;
3. less lag time from the moment the tow vehicle's brakes are actuated until the trailer brakes are actuated.
4. in emergency situations provide some braking independent of the tow vehicle.

### Brake Self-Adjusting Feature

Terran electric brakes may be equipped with a forward self-adjust feature enabling the brakes to adjust on both forward and reverse stops. Brake adjustment occurs when lining wear results in a larger gap between the shoes and the brake drum surface. When such a gap develops, the adjuster mechanism (deployed by rotating the screw at the bottom of the assembly) expands the distance between the brake shoes and reduces the gap between the shoes and the brake drum surface.

### Proper Brake Usage

Trailer brakes are designed to work in synchronization with your tow vehicle brakes. Never use your tow vehicle or trailer brakes alone to stop the combined load. To this end, brake controller must be set up according to the manufacturer's recommendations to ensure proper synchronization between the tow vehicle and the trailer. To accommodate changing loads and driving conditions, brake controller adjustments may be necessary to achieve synchronization. Importantly, read the brake controller manual before proceeding with brake synchronization.

Lack of synchronization can cause brake lockup or lack of smooth braking can be caused by lack of synchronization, excessive threshold voltage (over 2 volts) or under adjusted brakes. Proper synchronization can only be achieved through road testing. Before any synchronization adjustments are made your trailer brakes should be burnished-in by applying the brakes 30 times with approximately a 20 mph decrease in speed, e.g. 40 mph to 20 mph. Allow ample time for brakes to cool between application. This allows the brake shoes and magnets to begin "seating" to the brake drums.



---

Synchronization adjustments should only be done on burnished brake s. To check synchronization, make several hard stops from 20 mph on a dry, paved road free of any sand, gravel, water or ice. If the trailer brakes lock, follow the brake controller manual to adjust/decrease the gain. On the other hand, if the brakes do not lock, slightly increase the gain in accordance with brake controller manual. The controller should be adjusted to near the point of impending brake lockup and wheel skid.

Note: Not all trailer brakes are capable of wheel lockup. Load (weight and distribution), brake type and wheel & tire size can impact whether a brake will lock. For safety and proper function, it is not beneficial to lock up the brakes and slide the tires. This can result in uneven tire wear and loss of tow vehicle and trailer control.

If the brake controller engages the trailer brakes before tow vehicle brakes then the controller should be adjusted to achieve synchronization in accordance with the brake controller manual. The controller setting should enable the trailer brakes to engage slightly before tow vehicle brakes. If there is proper synchronization, the trailer will not jerk or push the tow vehicle during braking.

### CAUTION

**BEFORE ROAD TESTING, MAKE SURE THE AREA IS CLEAR OF VEHICULAR AND PEDESTRIAN TRAFFIC. FAILURE TO BRAKE SAFELY COULD RESULT IN AN ACCIDENT AND PERSONAL INJURY TO YOURSELF AND/OR OTHERS.**

## 6.1 General Maintenance – Electric Brakes

### CAUTION


**RAISE TRAILER ONLY WITH A SUITABLE FLOOR JACK AND JACK STANDS WHICH ARE APPROVED FOR THE LOAD. ATTACH JACK STANDS TO FRAME AND NEVER ATTACH JACK STANDS TO THE AXLE OR SUSPENSION. NEVER GO UNDER THE TRAILER UNLESSTRAILER IS SECURELY SUPPORTED BY JACK STANDS APPROVED FOR THE LOAD. FAILURE TO SECURELY SUPPORT THE TRAILER MAY CAUSE SERIOUS INJURY OR DEATH.**

### **Brake Adjustment**

Terran electric brakes that have a self-adjusting feature require no manual adjustment. Brakes not equipped with this feature can be adjusted by using the following procedure:

Brakes should be adjusted at 250 miles and every 3000 miles thereafter, or as use and performance requires. The brakes should be adjusted in the following manner:

1. Ensure your trailer is on a level surface and follow the trailer manufacturer's instructions for safely raising the trailer on jack stands designed to support your trailer type, size and weight.
2. Jack up the trailer until the wheel is clear of the ground and rotates freely.
3. Remove the cover from the adjusting hole on the backing plate.
4. Utilize a brake adjusting tool to turn the starwheel of the adjuster to expand the brake shoes until the wheel is difficult to turn. If the axle has a drop spindle, a special tool may be needed to complete the adjustment.
5. Then use the brake adjusting tool to turn the starwheel in the opposite direction until the wheel turns with a slight drag.
6. Return the cover to the adjusting hole on the backing plate.
7. Use the jack to return the wheel carefully to the ground.
8. Utilize this procedure for the other wheels and ensure all brakes are adjusted at the same time to a consistent slight drag on each wheel.



## 6.2 Brake Cleaning and Examination



### WARNING – ASBESTOS

Potential Asbestos Dust Hazard in Older Brake Linings

Follow Recommended Asbestos Safety Precautions in Servicing Older Brakes

As a general rule, brakes should be serviced after one year of operation to maintain optimal performance and immediately upon any failure or signs of less than optimal performance. In the event of heavy usage, brakes should be serviced more frequently. Change worn magnets and shoes as needed to maintain maximum braking capability.

Brake shoes, electromagnets, magnet arms and backing plates should be cleaned. Make sure that all the parts removed are replaced in the same brake and drum assembly. Inspect for any loose or worn parts, stretched or deformed springs and replace as necessary.

### 6.2.1 Electromagnet

Electromagnets should be inspected and serviced at least once per year for normal use. The surface of the magnet must be completely flat for proper operation. Replace the electromagnet if there is uneven wear on the electromagnet surface or exposure of the electromagnet coil. Qualified technicians recommend replacement or refinishing of armature surfaces whenever the electromagnet is replaced as well as replacement of the electromagnet on the other side of the brake. **Terran does not advise on whether or not an armature surface should be resurfaced or replaced.**

#### Brake Shoes and Linings

A visual inspection of your brake linings will indicate the level of wear.

Brake lining replacement is necessary if worn to 1/16" or less.



Brake shoes contaminated with grease or oil or abnormally scored or gouged should also be replaced. Hairline heat cracks are normal in bonded linings and should not be cause for concern but keep an eye on the extent of the cracks. When replacement is necessary, replace both shoes on each brake and both brakes of the same axle. This will help retain the “balance” of your brakes.

After replacement of brake shoes and linings, the brakes must be re-burnished to seat in the new components. This should be done by applying the brakes 30 times with approximately a 20 mph decrease in speed (e.g., 40 mph to 20 mph). Allow ample time for brakes to cool between applications. This procedure allows the brake shoes to seat into the drum surface.

### 6.2.2 Brake Lubrication

#### CAUTION

**WHEN LUBRICATING BRAKE PARTS, BE SURE TO AVOID ANY GREASE OR OIL CONTACTING OR BEING APPLIED TO, EITHER ACCIDENTALLY OR INTENTIONALLY, TO BRAKE LININGS, BRAKE DRUMS OR THE ELECTROMAGNETS. FAILURE TO DO SO COULD RESULT IN BRAKE MALFUNCTION AND RESULT IN SERIOUS INJURY OR DEATH.**

Before reassembling the brake drum, apply a light layer of approved brake grease or anti-seize compound to the brake anchor pin, actuating arm bushing and pin, actuating block and areas on the backing plate that are in contact with the brake shoes and electromagnet lever arm. **Do not lubricate brake linings, drums or electromagnets.**

### 6.2.3 Voltage Measurements

To check system voltage, connect the voltmeter to the two magnet lead wires at any brake. This may be accomplished by using a pin probe inserted through the insulation of the wires. The engine should be running when checking the voltage so that a low battery will not affect the readings. Voltage in the system should begin at 0 volts and as the controller bar is slowly actuated should gradually increase to about 12 volts. If the controller does not produce this voltage control, consult your controller manual. The threshold voltage of a controller is the voltage applied to the brakes when the controller first turns on. Lower threshold voltage will provide for smoother braking. If the threshold voltage is too high the brakes may feel grabby and harsh.






## Amperage Measurements

Braking System amperage is the amount of current flowing through the system when all magnets have been energized. Amperage is checked using an ammeter with sufficient capacity. The amperage will vary in proportion to the voltage. At the brake controller, first disconnect the (blue) wire running to the brakes and then connect the ammeter in series into the line. The engine should be running when checking the amperage. The following amperage chart sets forth acceptable ampere readings for brake systems.

Brake Size	Amps/Magnet	Two Brakes	Four Brakes	Six Brakes
10"×2 1/4"	3.0	6.0	12.0	18.0
12"×2"	3.0	6.0	12.0	18.0
12 1/4"×3 3/8"	3.0	6.0	12.0	18.0

If the brake system has a resistor, either set the resistor at zero or bypass before testing amperage in order to receive an accurate amperage reading. To check amperage for individual brakes, insert the ammeter at the magnet by disconnecting the magnet lead wires and attaching the ammeter between the two wires. Reconnect the wires after testing.





## 6.2.4 Troubleshooting Electric Brakes

### Troubleshooting Chart

PROBLEM	POSSIBLE CAUSE	REMEDY
No brakes	Open circuits	Find and correct
	Short circuits	Test and correct
	Severe under-adjustment	Adjust brakes
Weak brakes	Grease or oil on magnets or linings	Clean or replace
	Corroded connections	Clean and correct cause of corrosion
	Worn linings or magnets	Replace
	Scored or grooved brake drums	Machine or replace
	Improper synchronization	Correct
	Under-adjustment	Adjust brakes
	Glazed Linings	Re-burnish or replace
Locking brakes	Under-adjustment	Adjust
	Improper synchronization	Correct
	Loose, bent or broken brake components	Test and correct
	Out-of-round brake drums	Machine or replace
	Insufficient wheel load	Adjust system resistor and synchronize
Intermittent brakes	Broken wires	Test and correct
	Loose connections	Repair or replace
	Faulty ground	Find and repair
Brakes pull to one side	Wrong magnet lead wire color	Adjust
	Incorrect adjustment	Correct
	Grease or oil on linings or magnets	Clean or replace
	Broken wires	Find and repair
	Bad connections	Find and repair
Harsh brakes	Under-adjustment	Adjust
	Improper synchronization	Correct
Noisy brakes	Under-adjustment	Adjust
	Lack of lubrication	Lubricate
	Broken brake components	Replace component
	Incorrect brake components	Correct
Surging brakes	Grease or oil on linings or magnets	Clean or replace
	Out-of-round or cracked brake drums	Machine or replace
Dragging brakes	Over-adjustment	Readjust
	Out-of-round brake drums	Machine or replace
	Incorrect brake components	Replace
	Loose, bent or broken brake components	Replace
	Faulty breakaway switch	Repair or replace
	Loose wheel bearing adjustment	Adjust
Bent spindle	Replace Axle	



**NOTE:** If all coach lights and brakes do not work, check your wiring plug connection and make sure the ball is making solid contact with the coupler (that is how a coach is grounded). Too much grease or not using dielectric grease on the ball and coupler can cause this to happen.





## 6.3 Hydraulic Brakes

Hydraulic brakes use the force of a slowing tow vehicle to initiate trailer deceleration. The trailer is equipped with an actuation system to activate hydraulic brakes. As the tow vehicle brakes are engaged, force is applied to a hydraulic cylinder through the release of brake fluid and creation of pressure that activates the trailer brakes by forcing the brake shoes into the drum. The more force the driver puts on the brake pedal, the greater the pressure inside the brake lines, and the more the shoes will press against the drum resulting in increased deceleration.



### 6.3.1 Lubrication

Before reassembling the brake drum, apply a light layer of approved brake grease or anti-seize compound to the brake anchor pin, actuating arm bushing and pin, and areas on the backing plate that are in contact with the brake shoes. **Do not lubricate brake linings or drums.**



## 7. WHEELS & TIRES

### 7.1 Wheels Selection

When selecting wheels for your trailer, be sure to follow the proper tire and axle dimensions, load capacity and bolt layout. There are several key items to align: the drum bolt layout must match the wheel (carefully measure); the wheel load capacity and pressure rating must be consistent with maximum tire and trailer load capacity; and the offset must be consistent with the original wheel.

### 7.2 Wheel Installation

#### CAUTION

**FAILURE TO TIGHTEN LUG NUTS TO TORQUE LIMITS CAN DAMAGE STUDS AND LUG NUTS, CAUSE WHEEL LOOSENING AND IMBALANCE AND EFFECT STRUCTURAL DAMAGE TO THE WHEEL, STUDS AND LUG NUTS, AND MAY RESULT IN SERIOUS INJURY OR DEATH.**

#### CAUTION

**RAISE TRAILER ONLY WITH A SUITABLE FLOOR JACK AND JACK STANDS WHICH ARE APPROVED FOR THE LOAD. ATTACH JACK STANDS TO FRAME AND NEVER ATTACH JACK STANDS TO THE AXLE OR SUSPENSION. NEVER GO UNDER THE TRAILER UNLESS TRAILER IS SECURELY SUPPORTED BY JACK STANDS APPROVED FOR THE LOAD. FAILURE TO SECURELY SUPPORT THE TRAILER MAY CAUSE SERIOUS INJURY OR DEATH.**

1. Ensure your trailer is on a level surface and follow the manufacturer's instructions for wheel removal, including safely jacking up the trailer on jack stands designed to support your trailer type, size and weight.
2. Mount the wheel over the studs and begin to tighten the lug nuts by hand to prevent cross threading.
3. Tighten the lug nuts in the sequence to the torque values provided below.
4. Retorque the lug nuts before the first road use, after 50 miles of use and as necessary thereafter.

#### 7.2.1 Torque Requirements

Wheel Size	Stud Size	Torque Sequence		
		1st Stage	2nd Stage	3rd Stage
14"	1/2"	20-25 ft-lbs	50-60 ft-lbs	90-120 ft-lbs
15"	1/2"	20-25 ft-lbs	50-60 ft-lbs	90-120 ft-lbs
16"	1/2"	20-25 ft-lbs	50-60 ft-lbs	90-120 ft-lbs
16.5"×6.75"	1/2"	20-25 ft-lbs	50-60 ft-lbs	90-120 ft-lbs
16"	9/16"	20-25 ft-lbs	60-70 ft-lbs	120-130 ft-lbs
16.5"×6.75"	9/16"	20-25 ft-lbs	60-70 ft-lbs	120-130 ft-lbs



---

### 7.3 Tire Selection

Select the tire that matches wheel rim size and contour as well as trailer load capacity. Tire specifications are detailed in the manufacturer catalog and trailer load capacity is in the trailer operating manual. Importantly, increasing tire load capacity does not increase trailer load capacity. For your trailer, you will need to look for either LT (Light Truck) or ST (Specialty Tires) tires. Tire specifications located on the sidewall include tire dimensions, load capacities and purpose.








## 7.4 Tire Installation and Maintenance

### CAUTION

**TIRES SELECTED MUST BE COMPATIBLE WITH THE SPECIFICATIONS FOR THE WHEELS AND RIMS. FAILURE TO ACCURATELY PRESSURIZE IN ACCORDANCE WITH TIRE AND WHEEL SPECIFICATIONS COULD RESULT IN TIRE AND WHEEL FAILURE AND RESULT IN SERIOUS INJURY OR DEATH.**

Visually inspect tire sidewalls and treads and check the p.s.i. with a tire pressure gauge regularly (test when the tire is cold). Consult tire manufacturer manual for proper installation and maintenance.

	<p><b>Over Inflation</b> Excessive wear at the center of the thread indicates that the tire pressure is consistently too high.</p>
	<p><b>Under Inflation</b> This type of wear usually results from consistent under inflation or overloading.</p>
	<p><b>Feathering</b> The most common cause of feathering is incorrect toe-in setting.</p>
	<p><b>One Side Wear</b> There is excessive camber in the front suspension, causing the wheel lean too much to inside or outside and putting too much load on one side of the tire.</p>
	<p><b>Cupping</b> Wheel imbalance usually shows up as bald spots between the outside edges and center of the tread.</p>



## 8. POST-AXLE INSTALLATION CHECKLIST

### CAUTION

**ALWAYS USE EYE PROTECTION (SAFETY GLASSES) WHEN UNDERTAKING ANY SERVICE, MAINTENANCE OR OTHER PROCEDURE IN THIS MANUAL. FAILURE TO DO SO MAY RESULT IN SERIOUS PHYSICAL INJURY AND PERMANENT PHYSICAL DAMAGE.**

Prior to conducting the Post-Installation Inspection, confirm that the trailer or recreational vehicle is positioned on a flat surface.

#### 1. Gross Axle Weight Rating Check:

Confirm that the Gross Axle Weight Rating (GAWR) for the installed axles are suitable for the trailer or recreational vehicle. GAWR is the maximum amount of weight that can be placed on each axle. Check the axle label located at the axle center for the GAWR designated by the manufacturer.

#### 2. Tire Pressure:

Confirm using a tire pressure gauge (on cold tires) that tire pressure follows the manufacturer's recommendations.

#### 3. Tire Clearance:

Tire clearance is critical for safe operation as the axle moves during suspension travel. Each tire must be measured for sufficient tire clearance.

To check tire clearance, measure the distance between the outside of the tire and the nearest point of contact. Each tire clearance measurement must be performed with proper tire inflation at GAWR.

For spring axles, ensure at least 3" of tire clearance at GAWR.


#### 4. Wheel Nut Torque Values:

For each tire, check the torque values on each lug nut to confirm compliance with the Terran torque values under section entitled "Wheels & Tires."

#### 5. Equalizer Shackle Links Check:

For the tandem axle install: Verify the shackle links are pointing up to form the "W" shape, or in the 10 o'clock and 2 o'clock position.

See the below drawing for the proper positioning of the shackle links for a tandem axle installation.





6. Voltage & Amperage Check:

- A. Connect each voltmeter pin probe to a lead wire of the magnet for a brake. With the voltmeter connected to the lead wires and the engine running, as the brake is applied the voltage should increase from 0 to approximately 12 volts. If less than 10.5 volts, confirm that you followed the steps for the voltage test and then check for problems with the vehicle's electrical system. Repeat this test for each brake.
- B. To check amperage for each brake, insert the ammeter at the magnet by disconnecting the lead wires and attaching the ammeter between the two wires. Confirm at least 3 amperes. If less than 3 amperes, confirm that you followed the ampere test and then check for problems with the vehicle's electrical system. Reconnect the wires after testing.

**CAUTION**

**RAISE TRAILER ONLY WITH A SUITABLE FLOOR JACK AND JACK STANDS WHICH ARE APPROVED FOR THE LOAD. ATTACH JACK STANDS TO FRAME AND NEVER ATTACH JACK STANDS TO THE AXLE OR SUSPENSION. NEVER GO UNDER THE TRAILER UNLESS TRAILER IS SECURELY SUPPORTED BY JACK STANDS APPROVED FOR THE LOAD. FAILURE TO SECURELY SUPPORT THE TRAILER MAY CAUSE SERIOUS INJURY OR DEATH.**

- C. Confirm that each brake engages by rotating the drum carefully by hand. The drum will lock when the brakes properly engage. If the drum continues rotating, the brakes are not engaging. In this case, refer to the Troubleshooting Chart Section 4.2.4. Repeat steps 6A and B.

9. RECOMMENDED MAINTENANCE PROCEDURES & SAFETY CHECKS

Consult with the Terran Axle Operating Manual at [www.terranaxle.com](http://www.terranaxle.com) (click on Products and then Operating Manual) and other equipment supplier manuals for specific procedures for service, maintenance and troubleshooting of each component of your axles, including the suspension system.

Note that performing work on axles can lead to serious physical injury as well as property damage. Consult a qualified technician for assistance with service and maintenance.

<b>Component</b>	<b>Maintenance and Safety Check Procedure</b>
Brakes	For safe operation, recommend checking brake function at <u>every use</u> . If any concern or irregular response, immediately contact axle professional for inspection.
Brake Adjustment	Adjust brakes to proper setting 250 miles after burnishing (see burnishing procedure in Operating Manual) and every 3000 miles thereafter (more frequently if notice change in brake effectiveness).
Brake Drums	Visual inspection for excessive wear & tear or irregular wear marks. *See procedure in Operating Manual for removal of brake drums. Exercise care during removal and be precise when lubricating.
Armature	Visual inspection for wear & tear. Consult service professional to determine if surface refinishing or replacement is required.



---

Electromagnet	Visual inspection for wear & tear. Test for proper electrical operation. Replace if work unevenly.
Bearings	Visual inspection for wear & tear and sufficient lubrication. *See procedure in Operating Manual for bearing repacking.
Hubs	Visual inspection for wear & tear and any irregular wear, pitting, scratches or other unusual marks.
Seals	Visual inspection of seals for cracking, splitting or other damage. Pay close attention to grease build-up and leakage.
Springs	Monitor trailer or RV operating to assess whether springs are properly absorbing road impact. Visual inspection of springs for any defects or flattening of curves in springs. Check nuts and bolts to ensure proper torque values.
Suspension Components	Visual inspection for wear & tear in all bolts, nuts, connectors and other hardware and components after 50, 1000, 2000 and 3000 miles thereafter (more frequently if notice change in suspension effectiveness).
U-Bolts	Check torque values at 50, 1000, 2000 and 3000 miles and every 3000 miles thereafter (no less frequently than annually). *See torque values in Operating Manual.
Wheel Nut	Check torque values at 50, 1000, 2000 and 3000 miles and every 3000 miles thereafter (no less frequently than annually). *See torque values for Wheel Nut (also referred to as spindle nuts) in Operating Manual.

## 10. LIMITED WARRANTY

<https://www.terranaxle.com/warranty>

## 11. AXLE SPECIFICATIONS

<https://www.terranaxle.com/axles>